



IN BUSINESS



Series 54000

Installation, Operation, and Maintenance Instructions


Installation Procedure

- Unpack unit. Inspect carefully to make sure that all packing material, protective cardboard, tape and flange protectors are removed.
- The vent should be lifted by the multiple lifting lugs only. Do not lift by attachment to weatherhood or flange. Care should be taken to avoid damage to unit as it is being positioned in its mounting location.
- The vent setting is established at the factory per order specifications. No modifications or adjustments are required prior to vent installation.
- Mount vent to the appropriate flange using gaskets compatible with service conditions. For best performance, the vent should be mounted level so that the seating surface is no more than 1° off horizontal.

Caution!

If any questions arise concerning the proper installation or maintenance of our products, please contact Protectoseal or one of our Authorized Representatives.

When installing any Protectoseal device, the legal, corporate and advisory safety regulations and procedures appropriate for the specific installation site must be fully understood and followed.



Maintenance

Protectoseal recommends that our products be inspected and maintained according to the normal maintenance schedule of the facility. At a minimum, maintenance should be conducted annually. More frequent maintenance may be required, and should be scheduled, for unusual service conditions.

Caution!

When maintaining any Protectoseal device, the legal, corporate and advisory safety regulations and procedures appropriate for the specific installation site must be fully understood and followed.

Caution!

Tank vapor space pressure or vacuum should be relieved before any maintenance operations are undertaken.

Maintenance Procedure:

- Remove the lifting lugs from the studs. Remove hood nuts and weatherhood from vent. Remove the screen. NOTE: No spring forces are involved during these processes.
- Inspect vent and remove any loose dirt or foreign material from the unit or the hood. Inspect the screen and replace if damaged.
- The vent is designed so that all spring forces are contained by the spring package. The springs are compressed between the flange plate and upper spring guides (see Detail A).

Warning:

If it is necessary to disassemble the spring package, extreme caution must be exercised due to the high spring forces that may be present within the spring package assembly.

Spring Package Disassembly and Reassembly:

Measure the compressed height of the springs in the spring package (Seetail A) and record this dimension for later use

Note:

This compressed spring height is critical in that it establishes the set point of the vent.

- The studs on the vent are long enough so that all compressive force of the springs can be relieved as spring nuts are loosened. As the nuts are loosened, the spring guides will move upwards, relieving spring forces. The spring nuts should be loosened alternately and evenly so that each of the springs are allowed to expand evenly until the free length of the springs is reached.
- Once the spring forces have been relieved, the spring nuts, spring guides, springs and pallet assembly may be removed for inspection.
- Inspect the diaphragm. If the diaphragm is deteriorated it should be replaced. Make sure that the nut securing the diaphragm is fastened securely.
- Inspect the seating surface. It should be smooth and free of dirt or nicks. If necessary, clean the seating surface with an appropriate cleaner or solvent.

Caution:

Do not use a file or sharp tool that may damage the seat surface.

- Reassemble the spring package assembly in the reverse order to above. Install pallet assembly, lower spring guides, springs, upper spring guides and spring nuts. Slowly compress the springs by tightening the spring nuts evenly and alternately until the springs are at their compressed height that was measured in Step 1 of this process.

Note:

This compressed spring height is critical in that it establishes the set point of the vent.

- Tighten spring nuts to secure position of spring plate.
- Reinstall the screen, weatherhood, hood nuts and lifting lugs.



For Safety, Efficiency and Environmental Protection

■ Pressure/Vacuum Relief Vents

Pallets open and close to permit only the intake or outlet relief necessary to stay within permissible working pressures and avoid damage to tank.

■ Pipe-Away Relief Vents

Pressure/Vacuum relief for applications that require hazardous vapors to be processed into manifolded piping and not released into the atmosphere.

■ Emergency Vents

Protect tanks against rupture or explosion resulting from excessive internal pressure caused by exposure to fires. PIN-TECH® units featuring <500 ppm leakage available.

■ Flame Arresters

Prevent external flame entry into storage or processing tanks via vent opening.

■ Detonation Arresters

Withstand and arrest high velocity and pressure flame fronts approaching from either direction in closed or manifolded piping systems.

■ Tank Blanketing Valves

Control the flow of an inert gas into the vapor space of a storage tank so that the tank pressure can be maintained within an acceptable range.

Contact Protectoseal today to learn more
about our safety solutions and how our
maintenance services can keep your operations
secure and compliant.



The Protectoseal Company
(Headquarters)



Elmac Technologies Ltd.
T/A Protectoseal



Elmac Envisafe Technologies
Pvt. Ltd. T/A Protectoseal

info@protectoseal.com

1.630.595.0800

www.protectoseal.com

enquiries@protectoseal.uk

+44 1352 717 560

www.protectoseal.com

sales.eet@protectoseal.in

+91 22 4100 6998

www.protectoseal.com