


**Solenoid-Driven Metering Pump****PZiG Series****USER'S MANUAL**

**Before beginning operation, read this User's Manual carefully!**  
**Ignoring the descriptions in this User's Manual and mishandling the**  
**unit may result in death or injury, or cause physical damage.**

**— Applicable Models —**

PZiG-300  
PZiG-500  
PZiG-700  
PZiG-1000  
PZiG-1300

- Be sure to keep this User's Manual in a place where it will be easily available for reference.
- If the PZiG series pump you bought conforms to special specifications not described in this User's Manual, handle the pump according to details of separate meetings and drawings.

- TACMINA accepts no liability whatsoever for any damage caused by malfunction of this unit and other damage caused by use of this unit.
- Additional information on this product and manuals in other languages may be found on our website.



# For the Safe Use of This Product

This User's Manual is intended to help the operator to handle the product safely and correctly. In support of this aim, important safety-related instructions are classified as explained below. Be sure to follow them at all times.

## ⚠ WARNING

- If the product is operated incorrectly in contravention of this instruction, it is possible that an accident resulting in death or serious injury will occur.

## ⚠ CAUTION

- This indicates that improper operation can result in an injury or physical damage to the product.

## IMPORTANT

- This indicates information that should always be followed to maximize the product's performance and service life.

## NOTE

- This indicates supplementary explanations.

## Conditions of Use

## ⚠ WARNING

- This pump cannot be used in explosion-proof areas, and in explosive/ignitable atmospheres.

## ⚠ CAUTION

- This pump can be used for injection of chemicals only. Do not use this pump for other applications. Doing so might cause accidents or malfunction.
- This pump cannot be used for transferring fluids that contain slurry.
- The discharge volume cannot be adjusted by operating valves on the discharge piping.
- This pump generates pulsation. Install a pulsation attenuator such as a damper.
- Do not use this pump outside the operating ranges indicated below. Doing so might cause malfunction.

Ambient temperature	0 to 40°C* <sup>1</sup>	
Operating liquid temperature	0 to 40°C (freezing not allowed)	
Humidity	35 to 85% (freezing not allowed)	
Viscosity	Standard valve type	50 mPa • s or less
	High-viscosity valve type* <sup>2</sup>	3000 mPa • s or less
Max. discharge pressure	PZiG-300	1.0 MPa (0.5 MPa on the FTCT type with PTFE tube)
	PZiG-500	0.7 MPa (0.5 MPa on the FTCT type with PTFE tube)
	PZiG-700	0.4 MPa
	PZiG-1000	0.3 MPa
	PZiG-1300	0.2 MPa
	Installation location	1000 m above sea level or less

\*<sup>1</sup> The ambient temperature range is -10°C to 50°C during transportation and storage. Also, do not subject this pump to strong shock during transportation and storage.

\*<sup>2</sup> Install the chemical tank at a location higher than the pump using pressure boosting piping.

Also, note that the viscosity that can be transferred and the discharge volume change according to piping conditions and the nature of chemicals.

When transferring high-viscosity liquids, the discharge volume may fall below the specified maximum discharge volume depending on the characteristics of the liquid, transfer conditions and other factors.

Consult us separately when transferring high-viscosity fluids.

## Transportation, Installation & Piping

## ⚠ WARNING

- This pump is not made to explosion-proof specifications. Do not install this pump in explosion-proof areas or in explosive/inflammable atmospheres.
- Install this pump in a location where it will not come into contact with other people besides the operator.
- Reliably ground the ground terminal. Failure to do so might cause electric shock.

## **CAUTION**

- Connect the piping to the pump correctly.
- If this pump is dropped or becomes damaged, contact us or your supplying agent. Continued use of this pump might cause an accident or damage.

TACMINA Europe Representative Office

Hochstr.35,56235 Ransbach-Baumbach,Germany

Tel.+49(0)2623-928-345 Fax.+49(0)2623-928-507 E-mail:trade@tacmina.com

- Do not install this pump at humid or dusty location. Doing so might cause electric shock or malfunction.
- Be sure to connect and wire the ground lead (green) to prevent electric shock.
- When a tightening valve is located on the discharge piping, and when there is a risk of blockage, be sure to install a relief valve on the piping immediately on the discharge side of this pump. When a valve has been tightened or foreign matter clogs the discharge piping of the pump, the pressure in the pump may increase beyond the range indicated in the pump specifications. This may result in chemicals spurting out, damage to the piping or malfunction of the pump, which are dangerous.
- To prevent chemical leakage from the relief valve return piping, return the tip of the piping to a tank or other receptacle.
- This pump has an IP65 or equivalent construction, but install it in a location where it is not exposed to direct sunlight, wind, or rain and where there is no chance of the pump being submerged in water. Failing to follow this instruction may damage the pump or shorten its service life. If you will install the pump outdoors, we recommend installing a cover over the pump.
- When using water-diluted solutions in cold areas, chemicals may freeze in the pump head or piping, damaging the pump and peripheral parts. Be sure to install heating apparatus or heat insulation.
- Water used in the pre-shipment test may remain on pump liquid-end parts. When using chemicals that generate gas or harden due to reaction with water, be sure to drain any water and allow liquid-end parts to dry before use.
- In general, when the hoses become very hot, their ability to withstand pressure deteriorates. When using hoses, ensure that they are resistant to chemicals and can withstand the operating temperatures and pressures. Failure to do so may damage the hoses or cause the chemicals to spray out.
- The durability of hoses varies considerably depending on the chemical used, temperature, pressure, and UV rays. Inspect the piping, and replace it if it has deteriorated.
- Do not apply excessive force on the cover as it is made of plastic. Doing so might damage the cover.

## **Electrical Wiring**

### **WARNING**

- Do not operate this pump with wet hands. Doing so might result in electric shock.
- Do not turn the power ON during electrical wiring. Attach a "Work In Progress" label to the power switch.
- Reliably ground the ground terminal. Failure to do so might cause electric shock. Be sure to install a current leakage breaker.
- Do not disassemble the body or circuits.

### **CAUTION**

- Electrical wiring must be performed by personnel such as an electrician having specialist knowledge.
- Check the power voltage before wiring. Do not wire a power supply outside of the rated voltage range.
- Be sure to ground the earth lead (green-yellow) when wiring to prevent electric shock.

## **Operation and Maintenance**

### **WARNING**

- Only the operator or administrator is allowed to operate this pump.
- Do not operate this pump with wet hands. Doing so might result in electric shock.
- If anything unusual occurs such as smoke or a burning smell during operation, immediately stop operation and contact your supplying agent. Failure to do so might result in fire, electric shock or damage to the product.
- Do not disassemble the body or circuits.
- During air release, chemicals spray forcefully from the tip of the piping. Either release air using water or other safe liquid, or return the tip of the air release piping to the tank. During this operation, either hold the air release hose by hand or secure it in position.
- When a valve has been tightened or foreign matter clogs the discharge piping of the pump, the pressure in the pump may increase beyond the range indicated in the pump specifications. This may result in chemicals spurting out, damage to the piping or malfunction of the pump, which are dangerous. Check the valves before the operation.

## ⚠ CAUTION

- Before disassembling liquid end parts for maintenance or repair, be sure to turn the power OFF and make sure that no voltage is being applied to the pump.
- Do not turn the power ON during electrical wiring. Attach a "Work In Progress" label to the power switch.
- When handling liquid-end sections, be sure to wear protective coverings (rubber gloves, mask, protective goggles, chemical-resistant overalls, etc.) appropriate for the chemicals being used.
- Before maintaining or repairing the pump, be sure to release the discharge-side pressure, drain the chemicals from liquid-end sections, and wash the pump with water.
- Pump vibration sometimes causes hoses to become loose and disconnected. Before starting operation, make sure that tubes are secured in position and tightened.
- During operation, the surface of the pump sometimes reaches or exceeds 60°C. When touching the pump during operation, be sure to wear protective coverings that can resist high temperatures.
- Idling the pump for a long time may cause the pump to malfunction. Do not idle the pump for more than one hour.
- If a large amount of solutions or lubricating oil is attached to the pump case for a long period, remove them away to avoid deteriorating the case quickly.

## Other

## ⚠ CAUTION

- Do not remodel this pump.
- Adopt preventative measures such as a chemical drain ditch in case chemicals flood out of the pump. Also, install so that the chemical level does not rise up to the surface where the pump is installed.
- When disposing of used pumps, ask an authorized disposal expert to dispose of the pump in accordance with local laws and regulations.

## Checking the Product

When unpacking, please confirm the following items:

- (1) Is the enclosed product the same model you ordered?
- (2) Do the details on the pump nameplate match your order?

The pump nameplate contains the following information:

- Product name
- Type
- Maximum capacity
- Maximum pressure
- Stroke frequency
- Power supply
- Peak current
- Serial number

Example:

Solenoid-Driven Metering Pump	
TYPE: PZIG-1000-VTCF-12 x 18PVC-W-OE-EUP	
MAX CAPACITY : 60.0 l/h	MAX FREQ. : 300 spm
MAX PRESS : 3 bar 0.3 MPa	PEAK CURRENT : 4 A
VOLTAGE : 1φ 100-240V 50/60Hz	
SERIAL NO. : 067Z0464	
TACMINA CORPORATION Hochstr. 35, 56235 Ransbach-Baumbach, Germany	

- (3) Are all the accessories present and correct?

Please refer to the accessory list below.

- (4) Can you detect any damage due to vibration or shock during transportation?

- (5) Are there any loose or disconnected screws?

All TACMINA products are carefully checked prior to shipment. If, however, you find a defect, please contact your supplying agent.

### ■ Accessory List

Connection	12 x 18PVC
Anti siphonal check valve	1 pc
Strainer	1 pc
Braided house	3 m (dia.12 x dia.18)
Pump fixing bolt	4 sets (M8 x 45, w/washers, nuts)
User's Manual	1 copy

Connection	12 x 15PTFE
Anti siphonal check valve	— *1
Strainer	— *1
PTFE hose	3 m (dia.12 x dia.15)
Pump fixing bolt	4 sets (M8 x 45, w/washers, nuts)
User's Manual	1 copy

\*1 Please purchase these accessories separately.

Connection	FNPT1/2, FNPT3/4, MNPT3/4, VP20
Pump fixing bolt	4 sets (M8 x 45, w/washers, nuts)
User's Manual	1 copy

\* Please acquire the signal cable separately.

# Contents

## Outline

Explanation of Product .....	5
Names of Parts .....	5

## Installation

Installation .....	6
Piping .....	7
Electrical Wiring .....	10

## Operation

Operation .....	13
Air Release .....	14
Setting the Discharge Volume .....	14
Key Lock .....	25
When Stopping Operation for a Long Time .....	25

## Maintenance

Maintenance .....	26
Replacing the Diaphragm .....	27
Replacing the Valve Seat and Check Ball .....	28

## Setting Parameters

Setting Parameters .....	31
--------------------------	----

## Troubleshooting

Troubleshooting .....	33
-----------------------	----

## Specifications

Model Codes .....	36
Performance Specifications .....	37
Power Supply Specifications .....	37
I/O Signal Specifications .....	38
Other Specifications .....	38
Performance Curves .....	39
Discharge Performance of High-viscosity Liquids .....	40
Length of Discharge-side Piping and Discharge Volume .....	40
External Dimensions .....	41

Consumables and Spare Parts .....	45
After-sales Services .....	46

Outline

Installation

Operation

Maintenance

Setting Parameters


Troubleshooting

Specifications

# Explanation of Product

The metering pump PZiG Series accurately feeds a fixed amount of liquid for a fixed period of time. Liquid is fed by action of the check valve inside the pump head and volumetric changes in the pump head that occur by reciprocating motion of the diaphragm driven by the force of the electromagnet (solenoid). This structure ensures that the discharge volume per single operation of the pump is fixed. The pump can be used on a power supply within the voltage range 90 to 264 V. A CPU is located inside the pump, which means that various control action can be achieved by externally input signals and pre-input programs. Control action states can also be output to external devices.

## Names of Parts



# Installation




## WARNING

- This pump is not designed to explosion-proof specifications. It cannot be used in explosion-proof areas, and in explosive/ignitable atmospheres.
- Install the pump in locations out of reach of personnel other than an administrator.

- If you have forgotten to open a valve or foreign objects are blocking the piping on the discharge-side of the pump, an excessive pressure rise that will exceed the pump's specification ranges may occur, liquid may spray out or piping may be damaged, which is dangerous.

## Installation Site


- Install the pump in a location where it is not exposed to direct sunlight, wind, or rain. Also, if you will install the pump outdoors, we recommend installing a cover over the pump.
- Install the pump in a location that is well-ventilated during summer, and where chemicals will not freeze in winter.




- Leave enough space to allow easy access for maintenance and inspection work.



- Maintenance space.




- Install the pump on a flat horizontal surface and fix it securely to prevent it from vibrating during operation. If the pump is installed on an inclined surface, the pump may not be able to discharge properly or at all.



## Position of Installation Bolts

Use the four pump fixing bolts (supplied) to secure the pump in position.



# Piping

This section mainly describes hose connection type piping.  
Contact TACMINA separately for details of other types of piping.

## Requests during Piping

### ●Pulsation

- The hoses on this pump vibrate as this pump generates pulsation. Secure this pump in such a way that hoses do not vibrate.
- We recommend installing a damper to reduce pulsation. Contact TACMINA separately.

### ●Maintenance

- When disconnecting a hose for maintenance or other purposes and then reconnecting the same hose, cut about 10 mm off the end of the hose so that the end surface is flush before inserting.
- Before performing maintenance, open the discharge-side piping to release pressure to the air.

### ●Length of Piping

- If the hose is too long, pressure loss might increase, causing the pump's permissible pressure to be exceeded and overfeed to occur or the pulsation to occur on the piping.
- A total of three meters of hose is provided on the discharge and suction side. In particular, when extending the discharge-side piping beyond two meters, pressure loss might exceed the pump's maximum discharge pressure. So, a damper must be installed or thicker piping must be provided. Notify your supplying agent of (1) viscosity of the liquid, (2) length (positional relationship) of the piping, (3) specific gravity of the liquid, and other information. On the 1300 type, when extending the discharge-side piping beyond two meters, be sure to install a damper. Select a damper and the optimum piping size.

### ●Bending Hoses

- Provide sufficient margin (in the case of 12 × 18 mm dia. PVC braided hose, a radius of 100 mm or more) to prevent the hose from folding. Prevent hoses from being folded, rubbed, cut, or trodden on. Failure to do so might damage the hose.
- Keep the number of bends and joints that cause resistance to a minimum.

# Piping

The following examples show layouts for a hose connection type pump.


## Flooded Installation

### ●Floor installation procedure

The following explains an example where a TACMINA tank is used.

- (1) Remove the hose nut on the tank side, pass the suction-side hose through the nut, connect the hose to the suction valve on the tank, and tighten the hose nut.
- (2) Connect the hose to the suction-side hose joint on the pump by the same procedure as in (1) above.
- (3) In the same way, connect the discharge-side hose to the discharge-side hose joint on the pump.
- (4) Install the anti siphonal check valve at the injection point.
- (5) Connect the discharge-side hose to the anti siphonal check valve.

- We recommend installing a relief valve for automatically releasing abnormal pressure to air in the discharge-side piping.
- Install a pressure gage on the discharge-side piping to measure the pressure on the pump's discharge side.
- Install the pump as close as possible to the chemical tank.  
If the suction-side piping is too long, cavitation sometimes occurs and metering performance can no longer be ensured.




## Suction-lift Installation

### ●Tank-top installation procedure

The following explains an example where a TACMINA tank is used.

- Installing the pump on a chemical tank containing chemicals that are likely to generate bubbles is not recommended.
- The suction height of this pump is -1.5 m. The suction capabilities of this pump may be impaired if the valve seat in the pump head is dry.


- (1) Secure the pump at the specified position on the top of the tank using the fixing bolts (provided).
- (2) Remove the hose nut from the strainer, pass the hose through the nut and install the strainer.
- (3) Cut the hose so that the strainer is 30 mm above the tank bottom.
- (4) Pass the hose through the suction pipe cover and pump's suction-side hose nut, and connect the hose to the suction-side joint on the pump.
- (5) Set the suction pipe cover in position.
- (6) Install the anti siphonal check valve at the injection point.
- (7) Pass the discharge-side hose through the hose nut, and connect to the discharge-side hose joint on the pump.
- (8) Connect the discharge-side hose to the anti siphonal check valve.



# Piping


## Hose Connections

(1) Insert the hose fully to prevent it from falling out.



(2) Fully tighten the hose nut by hand.

(3) Wrap the nut with a cloth to prevent damage.  
(4) Use two water pump pliers to retighten one more rotation as shown in the figure below.




\* After starting operation, retighten the nut as needed.

### NOTE

Depending on the hose diameter, it may not be possible to insert the hose all the way to the base of the joint. Use dimension A in the figure as a guideline to connect the hose to the joint.

\* Applying excessive force may damage the hose.

\* This dimension should be taken only as a guideline as it may vary depending on the usage conditions.



Hose type	Hose diameter	Dimension A
PVC braided hose	$\phi 12 \times \phi 18$	2 mm or less
PTFE hose	$\phi 12 \times \phi 15$	5 mm or less

## Anti Siphonal Check Valve

An anti siphonal check valve is provided with this pump (except for FTCT type and high viscosity type). Use this anti siphonal check valve as long as it does not obstruct operation. Be sure to install the anti siphonal check valve in the following instances.


- When the injection point is open to air and chemicals are injected at a position lower than the level of chemicals in the chemical tank (to prevent siphoning)
- When a lot of chemicals exceeding the rated discharge volume are transferred (to prevent overfeeding)
- Overfeeding may occur if piping is too long even on the ascending piping.

### ●Installing the anti siphonal check valve (VTCE/ VTCF)

\* In the case of FTCT, though the shape differs the procedure is almost the same.


#### (1) Provide an Rc3/8, 1/2 female screw at the injection point.

The R1/2 or R3/8 male screw on the anti siphonal check valve is already cut.



#### (2) Wrap sealing tape around the male screw of the anti siphonal check valve and screw the screw into the injection point.

If it is difficult to screw in the screw, grip the gripping section of the nozzle with pliers or a similar tool, and re-tighten lightly.




When installing the hose with the anti siphonal check valve attached to the main piping, be sure to turn the hose nut by holding the gripping section.

If you turn the hose nut without holding the gripping section, the screw section on the nozzle side may become damaged.

### POINT

**When injecting chemicals into slender piping, cut the tip of the injection nozzle as required before use.**

Cut the tip so that it is positioned at the center of the piping into which chemicals are to be injected.




When the injection nozzle is too long compared with the piping aperture, cut the dotted section in the figure before use.

**We recommend installing the anti siphonal check valve via a valve, for example, for maintenance.**

Provide an Rc1/2 or Rc3/8 female screw and screw in.

Use a valve made of a material that is resistant to the chemicals to be used.



# Electrical Wiring

## ⚠ WARNING

- Do not operate this pump with wet hands. Doing so might result in electric shock.
- Do not turn the power ON during electrical wiring. Attach a "Work In Progress" label to the power switch.
- Reliably ground the earth terminal. Failure to do so might result in electric shock. Be sure to install a current leakage breaker.
- Do not disassemble the body or circuits.

## ⚠ CAUTION


- Electrical wiring must be performed by personnel such as an electrician having specialist knowledge.
- Check the power voltage before wiring. Do not wire a power supply outside of the rated voltage range.
- Be sure to ground the earth lead (green) when wiring to prevent electric shock.

## ● Connecting the AC power supply

Power cord (2 m) is already attached.

### Wiring Example


#### ● When operating the pump interlocked with a transfer pump



### NOTE


- When installing an overcurrent protective device on this pump, always install a circuit protector (CP) with regards to the operating time and shutoff current characteristics. (5 A medium-speed type)
- The circuit protector shown as the recommended protective device can also be used as the power supply switch, which can simplify wiring.
- A thermal relay (Th) offers protection from overheating due to an overloaded motor and is suitable for equipment that is continuously powered such as a motor pump, but it is not suitable for this pump which is intermittently powered. The pump may not work normally.

#### ● Standalone operation



### IMPORTANT

- Be sure to use a commercial power supply (power supplied from an electric power company) as the power supply.
- Power supplies that cannot be used:
  1. Power supply equipped with an AC power regulator
  2. Power supply on the output side of the inverter
- When receiving power via a transformer, be sure to use a transformer with a capacity of at least three times the maximum power consumption.
- Do not take power in from the same terminal as an induction motor (e.g. transfer pump). A high voltage may be generated, for example, when the power is turned OFF and damages the pump.



- To prevent malfunctions due to noise, wire the power supply wires and the signal leads separately.


# Electrical Wiring

## ●When exercising ON/OFF control frequently (every several tens of seconds, for instance) using pH control, etc.

When ON/OFF control over the pump is to be exercised frequently, do not exercise this control by turning the power of the pump ON and OFF. Instead, turn the pump ON or OFF by connecting the ON/OFF input signals from an external source to the stop input pins of the pump connector.

Turning the power of the pump ON and OFF frequently will subject the power supply and other circuits to a heavy load, possibly causing malfunction.

The pump can be stopped by inputting a no-voltage contact or O.C. signal as the stop input signal to pins 3 and 4 of the 4-pin connector. (The pump stops in the signal ON status.)



## Recommended Protective Devices

### (1) Circuit protector

(Protects the main power supply when this pump malfunctions)

Manufacturer	Model
Mitsubishi Electric	CP30-BA2P1-M5A
Fuji Electric	CP32D/5
Panasonic	BAC201505

### (2) Arrester


Use an arrester that is suitable for the power supply that you use. The arresters shown below are recommended for use with 100 V and 200 V power supplies.

Manufacturer	Model	
	100 VAC use	200 VAC use
M-System	MA-100	MA-200

### (3) Line filter

Manufacturer	Model
TDK	RSHN-2006


## Signal Lead Connections




A 4-pin/8-pin separation-type connector is used for the signal connections on this pump. The signal lead used is a multi-core round tough-rubber sheath cable. Though the size of the signal lead differs according to the number of signals to be used, select a signal lead that meets the following criteria:

- Cross-sectional area of 0.5 mm<sup>2</sup> or more
- O.D. 5 to 10 mm dia.

(Example) 4-pin connector, OMRON XS2F-D421-D80-F



(Example) 8-pin connector, OMRON XF2S-D821-DHO-C (2 m)



\*1 Keep "8" shield open without connecting to the ground.

\* Above pin layout shows the connector side. Accordingly the pump side should be viewed reversed.

# Electrical Wiring

## Signal Input

- About the signal input (SIGNAL IN) terminal

- a) When applying a no-voltage contact signal to the pulse input

Apply a no-voltage contact pulse from a device such as a pulse-transmitting flow meter. In this situation, the signal has no polarity. Use a pulse signal with low chattering. This is not suitable for general-purpose control relay contacts.

- b) When applying an open collector (drain) signal to the pulse input

The current orientation is determined by the characteristics of the elements of open collectors, open drains, and other semiconductor contacts. Connect the collector (drain) to + and the emitter (source) to common.

- c) When applying a current signal to the analog input type


Connect the signal leads (4 to 20 mA DC) so that + is connected to ② and - is connected to ④ common.

- For the signal specifications, see page 38.


## Distribution of Signal Leads

### When not using a signal distributor

#### ● Pulse signal




#### ● Analog signal




\* When one pump is removed due to maintenance or when one pump fails, the analog signal is interrupted and the other pump also stops. If you want to ensure that the other pump operates, please install a signal distributor.

### When using a signal distributor

#### ● Pulse signal



#### ● Analog signal



# Operation



## WARNING

- When handling liquid-end sections, be sure to wear protective coverings (rubber gloves, mask, protective goggles, chemical-resistant overalls, etc.) appropriate for the chemicals being used.
- If you forget to open the discharge-side valve or if foreign matter clogs the discharge-side piping, the pressure in the pump and pump head may increase beyond the range indicated in the pump specifications. This may result in the chemical leaking or spouting out, or in damage to the pump or piping. Check valves before starting pump operation.

### Check the following:


#### Before Operation

Check Point	Details to Check	Remarks
Pump head Joints	Check for looseness. If the joints are loose, retighten them.	When first operating the pump after maintenance, retighten in the same manner.
Chemical tank	Make sure that there are sufficient chemicals in the chemical tank. Replenish the chemical tank if necessary.	Pay particular attention when handling chemicals or performing processes that are adversely affected by contact with air.
Hose connections	Check for twisted or disconnected hoses. Reconnect or repair damage if necessary.	The twisted section may become deformed, resulting in damage or cracks.
Valves (suction side and discharge side)	Make sure that valves on the suction side and discharge side are open. Open any closed valves.	Closed valves may cause pressure to build up, chemicals to spurt out or damage piping.
Power supply	Make sure that the pump is connected correctly to the specified power supply.	The electronic circuit or solenoid may seize.
Electrical wiring - signal	Check for wrong connections.	Wrong connections may cause short circuits or electrical leakage.

#### During Operation

Check Point	Details to Check	Remarks
Pump head	Check for chemical leaks from the hole at the bottom of the auxiliary ring on the rear of the pump head.	If a chemical leak occurs, the diaphragm may be damaged. So, inspect the diaphragm.
Joints - hoses	Check for liquid leakage or looseness.	If there are chemical leaks, re-tighten joints. If this does not correct the chemical leaks, inspect each of the O-rings.
Discharge-side pressure	Check the needle of the pressure gage on the pump discharge side.	If an abnormal numerical value is indicated, the piping may be clogged or valves may be blocked. Inspect the piping also.

- When using the pump for the first time
- When restarting the pump after prolonged downtime
- When gas lock is occurring on the pump
- When the chemical tank is empty, for example, when the chemical tank is replaced



#### Release air (page 14)

- When using the pump for the first time
- When changing the discharge volume



#### Adjust the discharge volume (page 14)

- When stopping operation for a long time
- When restarting the pump after prolonged downtime



#### When stopping operation for a long time (page 25)

# Air Release



## WARNING

- During air release, chemicals spray forcefully from the tip of the piping. Either release air using water or other safe liquid, or return the tip of the air release piping to the tank.

## IMPORTANT

- Release air before pump operation when using the pump for the first time or when replacing the chemical container.

## Release Air by the Following Procedure


- (1) Release the pressure on the discharge-side piping to air.
- (2) Set the scale on the stroke length adjusting dial on the operation panel to 100%.
- (3) Turn the pump ON, set the number of strokes to 300 spm (100% or maximum discharge volume) and press the start button.

# Setting the Discharge Volume

## Outline

On the PZiG, the discharge volume can be set by performing the following setup on the operation panel. Before you set the discharge volume, calibration must be performed, and the maximum discharge volume per minute must be set in advance. For details on the calibration method, see "Calibration" (page 16).

## Operation Panel



- Manual mode** Sets the strokes (spm, %) or discharge volume (mL/min).
- Analog mode** The stroke spm is varied by an external signal (analog signal) to control the discharge volume.
- Pulse mode** The stroke spm is varied by an external signal (pulse signal) to control the discharge volume.
- Counter mode** Pump operation is performed for the number of preset strokes after the start signal is received to control the discharge volume.
- Interval mode** Pump operation is turned ON/OFF using an internal timer function to control the discharge volume.

## How to Apply/Cancel Selections by the UP/DOWN Keys


Table shows how to apply or cancel the contents that were input using the UP/DOWN keys.

Mode	To Apply	To Cancel
Calibration		
Analog		
Pulse (division/multiplication)	Press the SET key.	Do nothing for 5 seconds.
Count		
Interval		
Manual mode	Do nothing for 2 seconds.	To cancel, return the settings to their original settings.
Scaling (analog mode)	Press the FUNC key.	Return the settings to their original settings.

# Setting the Discharge Volume

## Operation Flow

Before changing the mode, stop pump operation and then press the MODE key.





\* Can be changed by the **▲▼** keys also while pump operation is stopped or during pump operation. (Determine when the numeric value changed from blinking to light on.)

# Setting the Discharge Volume

## Calibration

The calibration procedure is as follows. The figures below are for a PZiG-1000.

- (1) Install the pump and pump to match the actual piping conditions, and set to the trial operation mode
- (2) Pour the solution to be actually used into a measuring utensil (e.g. graduated cylinder) capable of measuring the maximum discharge volume per minute of pump operation.
- (3) Insert the suction-side end of the pump piping into the graduated cylinder, and release air.  
\* It is more convenient to use the measuring piping if this is provided on the tank.
- (4) Turn the stroke length adjusting dial to set the actual stroke length to be used. Do not change the stroke length after the maximum discharge volume has been set.
- (5) Press the MODE key several times until the display changes to mL/min.  
If the pump is operating, press the STOP key to stop pump operation before performing this operation.
- (6) Press the SET key to display the discharge volume setup screen. Press the FUNC key to enter the calibration mode.




- (7) Note down the level of the solution in the graduated cylinder.

- (8) Press the START key.

The pump operates for one minute (300 times) and comes to a stop.

- (9) Check the level of the solution in the graduated cylinder, and measure the amount of decrease of the solution.
- (10) Press the FUNC to return to the discharge volume setup screen.



- (11) Press the UP/DOWN key to set to the value calculated in step (9). (when the measurement value is 1010 mL)

- (12) Press the SET to return to the discharge volume setup screen.

## Remarks

When the screen returns to the discharge volume setup screen, the discharge volume setting value will not change. However, the stroke spm of the pump has changed.

- (13) Set the discharge volume as necessary using the UP/DOWN key.
- (14) Turn the pump OFF, and restore the piping.

## ■Calibration

The specification capability of this pump is the maximum discharge volume at 300 strokes (on the PZiG-1000, 1000 mL/min). However, the discharge volume does not always match the actual discharge volume depending on the operating conditions, product differences, and stroke length setting.

For this reason, the actual discharge volume per 300 strokes is measured, and the maximum discharge volume is stored to the pump's memory. This eliminates any error between the preset discharge volume on screen and the actual discharge volume.

# Setting the Discharge Volume

## Manual Mode

### ●Basic operation

In the manual mode, the discharge volume can be set by the following methods:


- By changing the stroke spm (1 to 300 spm)
- By changing the ratio (1 to 100%)
- By changing the discharge volume (0.1 to maximum discharge volume mL/min)

### ●Purpose of use

The manual mode is used for the following purposes:

- Regular operation
- Test operation during pump installation, for example
- Provisional operation during an abnormality (e.g. signals are not output) in automatic operation

### ●Operation panel display



## Setting Manual Mode (changing the number of strokes)

Display	Operation	Explanation
		In the manual mode, the number of strokes can be changed during pump operation or when pump operation has stopped.
		In other modes, stop pump operation by the STOP key, and press the MODE key several times to set the manual mode. Default is 300 spm.
		Press the UP/DOWN key to set the number of strokes within the range 0 to 300 spm. (in single step increments)
		The number of strokes (spm) blinks.
		If you do not touch any of the keys for two seconds after setting the number of strokes, the numerical value you entered is determined, and the number of strokes stops blinking and lights.
		This completes changing of the setting value.
		If the pump has stopped, press the START key to start operation.
		The pump enters the run mode, and STP goes out.
		* If the screen on the left is displayed during pump operation, the number of strokes can be changed. Press the UP/DOWN key to change the number of strokes.
		If you do not touch any of the keys for two seconds after changing the number of strokes, the change is reflected.

### ●External stop signal

Basically, there is no need to supply signals from the outside in the manual mode. However, operation can be paused by a stop input (continuous signal) from the outside.

# Setting the Discharge Volume

## Setting Manual Mode (changing the ratio)

Display	Operation	Explanation
	   	In the manual mode, the ratio can be changed during pump operation or when pump operation has stopped.  In other modes, stop pump operation by the STOP key, and press the MODE key several times to set the manual mode.  Default is 100%.
		Press the UP/DOWN key to set the ratio within the range 1 to 100 %. (in 1% step increments)
		The number of % blinks.
	 	If you do not touch any of the keys for two seconds after setting, the numerical value you entered is determined, and the number stops blinking and lights.
		This completes changing of the setting value.
	 	If the pump has stopped, press the START key to start operation.
		The pump enters the run mode, and STP goes out.  * If the screen on the left is displayed during pump operation, the number of % can be changed. Press the UP/DOWN key to change the ratio.
		If you do not touch any of the keys for two seconds after changing the ratio, the change is reflected.

## Setting Manual Mode (changing the discharge volume)

Display	Operation	Explanation
	   	In the manual mode, the discharge volume can be changed during pump operation or when pump operation has stopped.  In other modes, stop pump operation by the STOP key, and press the MODE key several times to set the manual mode.
		Default varies depending on the model.
		Press the UP/DOWN key to set the discharge volume within the range 0.1 to the maximum discharge volume mL/min*. (in 0.1mL/min. step increments)
		The number of mL/min. blinks.
	 	If you do not touch any of the keys for two seconds after setting, the numerical value you entered is determined, and the number stops blinking and lights.
		This completes changing of the setting value.
	 	If the pump has stopped, press the START key to start operation.
		The pump enters the run mode, and STP goes out.  * If the screen on the left is displayed during pump operation, the number of mL/min. can be changed. Press the UP/DOWN key to change the discharge volume.
		If you do not touch any of the keys for two seconds after changing the number, the change is reflected.

\*1 The discharge volume is actually controlled every 1 spm.

The minimum controllable unit is the discharge volume x (max. discharge volume/300) per single stroke.


# Setting the Discharge Volume

## Analog Mode

In the analog mode, analog signals from an external device are received, and automatic operation is performed within the range 0 to 300 spm according to the setting values (set point (SP), and proportional band (PB)).

First, perform scaling according to the application of this pump, and then set the set point. Set the ramp of the stroke with respect to analog output as a proportional band (increment value: 1 to 999%, and decrement value: -1 to -999%), and linearly vary the number of strokes according to the analog input signal from the external device.

### ●Relationship between scaling and set point/proportional band



### ●Scaling

Normally, perform scaling before setting the set point. Set points matched to the target application can be set by performing scaling. Scaling details can also be changed after the set point is set. However, in this case, the target value is automatically changed according to the newly changed scaling details.

The following summarizes the scaling ranges that can be selected.

### ●List of scaling selections

No.	Scaling Range	Indication on Operation Panel	Settable Unit	Application
0	0 to 100	0 100 %	1 step (Step 1)	Standard
1	0.0 to 14.0	1 14.0	0.1 step (Step 0.1)	pH
2	0.00 to 1.00	2 1.00	0.01 step (Step 0.01)	Residual chlorine
3	0.00 to 2.00	3 2.00	0.01 step (Step 0.01)	Residual chlorine
4	0.00 to 5.00	4 5.00	0.01 step (Step 0.01)	Residual chlorine
5	0.0 to 10.0	5 10.0	0.1 step (Step 0.1)	Residual chlorine
6	0.0 to 20.0	6 20.0	0.1 step (Step 0.1)	Residual chlorine
7	0.0 to 50.0	7 50.0	0.1 step (Step 0.1)	Residual chlorine
8	0 to 100	8 100	1 step (Step 1)	Residual chlorine
9	0 to 200	9 200	1 step (Step 1)	Residual chlorine

\* On the operation panel, the selected scaling No. and the maximum value of the scaling range are displayed.

## Setting Scaling in the Analog Mode


Display	Operation	Explanation
	  	If the pump is operating, press the STOP key to stop pump operation.
	 	If the screen on the left is not displayed, press the MODE key until it is displayed.
		Press the SET key with pump operation stopped to enter the set point setting screen.
		Press the FUNC key to enter the scaling change screen.
		The screen on the left shows that scaling No.1: 0.0 to 14.0 is currently selected.
		For details on scaling selection details, refer to the "List of scaling selections."
		Press the UP/DOWN key to select scaling.
		Press the FUNC key to apply the selected details.
		When a scaling No. has been changed to a different No., the scale of the set point is automatically changed.
		Next, set the set point.
		Proceed to "Set the set point by the UP/DOWN key" on the 11th line of "Setting Set Point/Proportional Band in the Analog Mode" on the following page.

# Setting the Discharge Volume


## Set Point/Proportional Band in the Analog Mode

### ●Set point (SP)

For the set point (SP), set a target value on the X-axis (horizontal axis).




Example: When the SP is 75% (scaling No.0)



### ●Proportional band (PB)

With the proportional band (PB), set the inverse number of the line's ramp.

Example: When the PB is 100%



$$\text{Proportional band (PB)} = (\Delta X / \Delta Y) \times 100 \\ = (1/1) \times 100 = 100\%$$

### ●Purpose of use


These settings are used for proportional injection, for example.

## ●Operation panel display (when scaled by pH)


When the pump is stopped




During setting of SP



During pump operation



During setting of PB



## ●Operation control signal

4 to 20 mA DC

## Setting the Set Point/Proportional Band in the Analog Mode

Display	Operation	Explanation
STP ANG 4-20	START STOP MODE	If the pump is operating, press the STOP key to stop pump operation.
STP ANG 4-20	SET RESET	If the screen on the left is not displayed, press the MODE key until it is displayed.
STP ANG 4-20	UP DOWN	Press the SET key to enter the set point setting screen. "S" is displayed so that you can tell that the screen is the set point setting screen.
STP ANG 4-20	UP DOWN	Press the UP/DOWN key to set the set point. The setting range is the same as the selected scaling range.
STP ANG 4-20	SET RESET	The following instance is for scaling No.1 0.0 to 14.0 (for pH). To operate the pump at 100% capacity at pH 0 and stop operation at pH 7.0 in alkali injection, set 7.0 as the SP and -50% as the PB. The screen on the left shows that the set point is set to 7.0.
STP ANG 4-20	UP DOWN	The setting value is displayed but not yet applied.
STP ANG 4-20	SET RESET	To apply the value, press the SET key. After the value is applied, the screen enters the proportional band (PB) setting screen. The default is 100%.
STP ANG 4-20	UP DOWN	"P" is displayed so that you can tell that the screen is the proportional band setting screen.
STP ANG 4-20	UP DOWN	Press the UP/DOWN key to set the proportional band. The setting range is -999 to 999% (excluding 0).
STP ANG 4-20	SET RESET	The setting value is displayed but not yet applied.
STP ANG 4-20	START STOP	To apply the value, press the SET key. The state returns to the stopped state in the analog mode.
150 35	START STOP	Press the START key to start pump operation.
150 35		The upper row displays the number of strokes.

# Setting the Discharge Volume

## Pulse Frequency-division Mode

### ●Basic operation

- (1) Pulse signals from the outside are received, and automatic operation is performed according the frequency-division ratio setting.
- (2) The frequency-division ratio can be set within the range 1/1 to 1/9999.

Frequency-division (settable within range 1/1 to 1/9999)


(Example) 1/5 division



### ●Purpose of use

- This mode is used for flow rate proportional injection, etc. (The pump operates according to the number of input pulses from the outside)
- This mode is used when there is a large number of pulses for a flow meter, and the injection amount is too great.
- \* Perform fine adjustment of the discharge volume by also using the stroke length adjusting dial.

### ●Operation panel display



## Setting Pulse Frequency-division Mode

Display	Operation	Explanation
		If the pump is operating, press the STOP key to stop pump operation.
		If the screen on the left is not displayed, press the MODE key until it is displayed.
		The pulse division mode default is as follows: dividing ratio 1, and stroke speed interval of 300 spm (maximum stroke speed). (When the display indicates 1, the set dividing ratio is 1/1.)
		DIV is displayed on screen.
		Press the SET key to enter the dividing ratio setting screen.
		The current value starts blinking.
		Change the dividing ratio setting by the UP/DOWN key within the range 1 to 9999.
		In this frequency-division ratio setup, the numerator is fixed at 1. So, set the denominator.
		Press the SET key to determine the setting value.
		When the setting value is determined, the operating number of strokes setup screen is entered.
		(The number of strokes on the upper row starts blinking.)
		Normally, this item does not need to be changed. The injection amount can, however, be limited when there are too many pulse signals.
		Change the operating number of strokes setting by the UP/DOWN key within the range 1 to 300 spm.
		Determine the setting value by the SET key.
		When the setting value is determined, the display stops blinking and lights.
		The screen on the left shows that one single operation of the pump is performed for every three pulses. (The maximum stroke speed is 300 spm.)
		Press the START key to enter the pump operation mode.
		STP goes out, and the pump enters the pump operation mode.
		The pump starts to operate according to external pulse signals. (ON lights when a pulse signal is input.)

### ●Operation control signals

No-voltage contact or open collector signal input

# Setting the Discharge Volume

## Pulse Multiplication Mode


### ●Basic operation

- (1) Pulse signals from the outside are received, and automatic operation is performed by the number of strokes corresponding to the preset multiplication.
- (2) The multiplication can be set within the range 1 to 9999. at this time, the pump operates at the number of operation strokes (spm) set in the manual mode.


Multiplication (Can be set within the range 1 to 9999)

As the default setting, external signals are canceled when an external pulse input signal is input again during pump operation. You can set to put the external pulse input signal on hold and store it in memory in parameters (P-15, 16).

(A) The pump operates 5 times at a stroke speed of 300 spm (default).



(B) The pump operates 5 times at a stroke speed of 1 to 300 spm (user setting). (The pump setting becomes 0.4 seconds when 150 spm is set.)




\*Solutions are mixed more uniformly during inline injection.

### ●Purpose of use

- This mode is used for flow rate proportional injection, etc. (The pump operates proportionally to the number of input pulses from the outside)
- Use when there are few pulses from a flow meter or other instrument, and the injection amount is too small.
- Fine-adjustment of discharge volume is performed by the stroke length adjusting dial.

### ●Operation panel display



### ●Operation control signal

No-voltage contact or open collector signal input

## Setting the Pulse Multiplication Mode

Display	Operation	Explanation
		If the pump is operating, press the STOP key to stop pump operation.
		If the screen on the left is not displayed, press the MODE key until it is displayed.
		The default of the pulse multiplication mode is 1, and the default number of strokes is 300 spm (maximum number of strokes).
		Press the SET key to enter the multiplication setting screen.
		The current multiplication starts blinking.
		Change the multiplication setting by the UP/DOWN key within the range 1 to 9999.
		Press the SET key to determine the set multiplication.
		When the setting value is determined, the operating number of strokes setup screen is entered. (The number of strokes on the upper row starts blinking.)
		Change the operating number of strokes setting by the UP/DOWN key within the range 1 to 300 spm.
		Determine the setting value by the SET key.
		When the setting value is determined, the display stops blinking and lights.
		The screen on the left indicates that the pump operates five times for every single pulse at 150 spm (0.4 second) intervals.
		Press the START key to enter the pump operation mode.
		STP goes out, and the pump enters the pump operation mode. The pump starts to operate according to external pulse signals. (ON lights when a pulse signal is input.)

# Setting the Discharge Volume

## Count Mode

### ●Basic operation


- (1) The start signal is received and the pump operates for the number of preset times. (batch processing)
- (2) The setting value can be set by a combination of 1 to 9999 times and  $\times 1$ ,  $\times 10$ ,  $\times 100$ ,  $\times 1000$  multiplication. (1 to 9999, 10 to 99990, 100 to 999900, 1000 to 9999000)
- (3) The start signal can be selected from an external input and START/STOP key.
- (4) The end signal can be output when operation when operation for the preset count ends.

### ●Purpose of use


This mode is used in site where fixed amounts are repeatedly injected. (Operation can be easily instructed or confirmed from the outside by the start and end signals, for example, during batch injection to a container on a conveyor belt.)

### ●Operation panel display


During pump stoppage




During setup



During setup  
(multiplication)



During pump operation



### ●Operation control signal

#### [Start signal]

No-voltage contact or open collector signal input  
START/STOP key

## Setting Count Mode

Display	Operation	Explanation
		If the pump is operating, press the STOP key to stop pump operation.
		If the screen on the left is not displayed, press the MODE key until it is displayed.
		The default count is 10x1, and the default number of strokes is 300 spm (maximum number of strokes).
		Press the SET key to enter the count setting screen.
		The current count starts blinking.
		Change the count setting by the UP/DOWN key within the range 1 to 9999.
		Press the SET key to determine the set count. When the setting value is determined, the count multiple setup screen is entered. X... is displayed blinking.
		Change the count multiple by the UP/DOWN key to one of $\times 1$ , $\times 10$ , $\times 100$ or $\times 1000$ scales.
		Press the SET key to determine the set count multiple. When the "count x multiple" is 10000 or more, the value is displayed as a 4-digit count OOOO x 1000.
		For example, in the case of a total 30000 count (count: 300, multiple: x 100), this is displayed as 3000X10 on screen.
		When the setting value is applied, the screen enters the operating number of strokes (stroke speed) setting screen.
		Change the operating number of strokes setting by the UP/DOWN key within the range 1 to 300 spm.
		Determine the setting value by the SET key. When the setting value is determined, the display stops blinking and lights.
		The screen on the left indicates that the pump operates 350 times at a speed of 300 spm (0.4 second intervals) when the start signal is received, and then stops operating.
		Press the START key to enter the pump operation mode.
		The pump operates by an external start signal or by pressing the START key. (Start of pump operation by an external start signal or by the START key can be selected in parameter P-31.)


# Setting the Discharge Volume

## Interval Mode

### ●Basic operation

- (1) Intermittent operation by the preset ON and OFF times is repeated.
- \* The ON/OFF state during a start can be changed by parameters.
- (2) The setting values of each of the ON and OFF times is set from to 1 to 9999 minutes (in 1-minute increments).
- (3) Operation can be paused by input of an external stop signal.

When the parameter (P-30) is 0 or 1



Operation Time Chart

- 1) T1=ON time setting (1 to 9999 min)
- T2=OFF time setting (1 to 9999 min)
- 2) When the stop signal turns ON, counting of both T1 and T2 is discontinued.


\* When an external stop is determined, timers in the interval mode also are paused.

### ●Purpose of use

This mode can be used in sites where control is performed by alternate ON/OFF operation.

- Can be used for skipped operation at sites, for example, small amounts of chemicals are injected for air conditioning sterilization.
- Small amounts can be injected by combining intermittent operation and stop input.


### ●Operation panel display



### ●Operation control signal

Stop input: Operation is paused by input of an external stop signal.

## Setting the Interval Mode




# Key Lock

Keys can be locked to protect setting values.


The STOP/START key can be operated even when the key lock is active.

(1) Set the mode that you want to lock, and press the STOP key to stop the mode.



STP is displayed to indicate that the mode is stopped.


(2) Hold down the SET key for at least two seconds with the FUNC key held down.



2 seconds or longer


This enables the key lock, and operations other than the STOP/START key are disabled. When the key lock is enabled, ■ is displayed on the lower row.

(3) Press the START key to start operation.



This starts operation.

(4) To cancel the key lock, stop pump operation, and hold down the SET key for at least two seconds with the FUNC key held down again.



2 seconds or longer

This cancels the key lock, and enables all operations. When the key lock is canceled, ■ goes out.

## NOTE

- During the key lock, all operations are disabled except use of the STOP/START key and cancellation of the key lock.

# When Stopping Operation for a Long Time

Perform the following operation when stopping operation for a long time (e.g. due to an off season) and restarting pump operation after a prolonged downtime.

## When Stopping Operation

- Wash inside the pump head.  
Suck in and discharge clean water or diluted detergent for about 30 minutes.
- Remove the clean water or cleaning solution and stop the pump, then completely turn the power off.
- Attach the pump's protective cover.  
Adopt other measures to prevent dirt or dust from accumulating on the pump, and protect the pump from corrosive environments.
  - ambient temperature -10~50°C
  - ambient humidity 35~85% (freezing not allowed)

## When Resuming Operation

- Check the inside of the tank for sediment, clouding of chemicals and other abnormalities. If the chemicals inside the tank have deteriorated, drain the chemicals, wash the inside of the tank with water, and completely replace with fresh chemicals.
- Check the liquid-end sections for deterioration and that there is no adhesion of dirt or other matter.

# Maintenance




## WARNING

- When handling liquid-end sections, be sure to wear protective coverings (rubber gloves, mask, protective goggles, chemical-resistant overalls, etc.) appropriate for the chemicals be using used.
- Do not turn the power ON during maintenance. Attach a "Work In Progress" label to the power switch.
- Before disassembling liquid-end sections, be sure to release the discharge-side pressure, drain the chemicals from liquid-end sections, and wash them.


### Periodic Inspection

- 4000 hours of operation or once every year
- Abnormal discharge (reduced discharge volume)
- Chemical leakage around the pump head



**Replacing the diaphragm (page 27)**


- 4000 hours of operation or once every year
- Abnormal discharge (reduced discharge volume)



**Replacing the valve seat and check ball (page 28)**

### When an Abnormality Occurs

- Abnormalities during operation



**Troubleshooting (page 33)**


## NOTE

- Perform maintenance and inspection every 4000 hours of operation or once every year, whichever comes first.

# Replacing the Diaphragm


## IMPORTANT

When fixing the pump head using the head bolts, tighten the bolts in the order shown below a little at a time using even force. For example, tightening will be uneven if the bolts are tightened in the order 1, 3, 5 and 2. This might cause chemicals to leak from the pump head.



## Removing the Pump Head

- (1) Remove the six head bolts.
- (2) Remove the pump head.



## Replacing the Diaphragm/Protective Diaphragm

### (3) Remove the diaphragm.

Remove the diaphragm by holding its outer periphery and turning counterclockwise.


### (4) Remove the auxiliary ring to remove the protective diaphragm.

### (5) Replace with a new protective diaphragm, and set the auxiliary ring in position.

### (6) Install the new diaphragm. Firmly turn the diaphragm clockwise as far as possible.

If the diaphragm is loose, it may contact the pump head and cause a malfunction or become damaged.

### (7) Install the pump head.




# Replacing the Valve Seat and Check Ball


- Attach O-rings, ball stoppers and check balls making sure that they face the correct direction.
- When removing and re-fitting in the upper/lower joints, make sure that you do not mistake the upper and lower joints.
- Also, make sure that the O-rings and check balls are not scratched, and dust or dirt is not sticking to the valve seat.

## PZiG-300/500-VTCE/VTCF

A component kit comprising consumable parts (diaphragm and valve seats) is available.




## PZiG-700/1000/1300-VTCE/VTCF





\*Consumable

## PZiG-300/500/700/1000/1300-VTCF (High viscosity specification)



\*Consumable


**PZiG-300/500/700-FTCT****PZiG-1000/1300-FTCT**

\*Consumable

# Setting Parameters

For defaults, see page 32.

## Parameter Setup Flow



\* The parameter setting screen is entered from the manual mode (pump stopped state).

\* Changes made to parameter settings are applied when the SET key is pressed in the setting change screen.

## Setting Parameters

Display	Operation	Explanation
STP MAN 100 spm		Make sure that STP, MAN and spm are displayed.
P - 01	SET RESET ▲ ▼	First, enter the parameter setting screen by holding down the SET and UP keys for at least 5 seconds.
P - 10	▲ ▼	This is the parameter number selection screen.
P - 10	SET RESET ▲ ▼	Change to the desired parameter number by the UP/DOWN keys. (See Parameter List on page 32.)
P - 10	SET RESET ▲ ▼	When the desired parameter number is displayed, press the SET key to enter the parameter setting change screen.
P - 10	SET RESET ▲ ▼	The current value is displayed.
P - 10	SET RESET ▲ ▼	Set the parameter referring to the Parameter List on page 32.
P - 10	SET RESET ▲ ▼	Press the SET key to apply the selected value.
P - 10	FUNC	The original parameter No. is displayed.
STP MAN 100 spm		

\* You can continue to change other parameter settings until you press the FUNC key.

# Setting Parameters

## Parameter List

No.	Item	Details	Parameter	Default	Explanation
P-01	Internal processing			0	Used for internal processing. Cannot be set by the user.
P-02	Digital input	Input 1	See Table 1.	1	Can be selected from Table 1. Only the selected function is enabled.
P-03		Input 2	See Table 1.	2	
P-04		Input 3	See Table 1.	3	
P-05		Input 4	See Table 1.	4	
P-07	Digital output	Output 1	See Table 2.	1	Can be selected from Table 2. Only the selected function is enabled. (Port and functions are assigned simultaneously.)
P-08		Output 2	See Table 2.	2	
P-10	Analog input	Input signal type	0:4-20	0	Used for internal processing
P-15	DIV/MUL	Surplus pulse signal count	0: none 1 to 9999 buffer size	10	Changes the number of pulses that are held.
P-16		Surplus pulse at external stop	0: Save 1: Reset	0	Sets whether to save or clear surplus pulses at an external stop.
P-20	Display	Discharge volume setting max. value	0:1~9999mL	***	Discharge volume max. value (differs according to model)
P-22	Unit	Flow rate basic unit	0:mL/min 1:GPH	0	Select the display basic unit.
P-23	Mode screen display	ANG	0: Disabled 1: Enabled	1	Hides the mode when "Disabled" is selected.
P-24		DIV	0: Disabled 1: Enabled	1	
P-25		MUL	0: Disabled 1: Enabled	1	
P-26		CNT	0: Disabled 1: Enabled	1	
P-27		INT	0: Disabled 1: Enabled	1	
P-30	INT	Operation at start	0: ON (hold) 1: OFF (hold) 2: ON (clear) 3: OFF (clear)	0	Initial operation when pump operation is started. Selects whether to return timer states to their defaults or hold them at an external stop.
P-31	CNT	Start trigger	0: Start key 1: External input	1	Selects the start reset method.
P-32	Alarm operation	Level	0: Continue operation 1: Pause 2: Stop pump operation	1	Select operation when an alarm is generated.
P-33		Pulse overflow		0	Pause: Pauses pump operation when an alarm is output, and automatically restores pump operation when the function is canceled.
P-34		Analog error		1	Stop pump operation: Pump operation is not resumed until the start key is next pressed.
P-38	Alarm	Delay time	0 to 999 sec.	0	Provides a delay time until display/output when an error is generated.
P-44	Backlight	Lighting of backlight	0: OFF 1: ON	1	Sets whether or not to light the backlight.
P-45	Power restore	Forced stop at power restore	0: Reset and stop 1: Continue operation	1	Sets the operation state when the power is turned ON again.
P-46	Reset	Restore defaults at shipment from factory	0: Disabled 1: Enabled	0	When "1" is selected and the SET key is pressed, all settings are initialized and returned to their defaults.
P-47	Diagnostics	Diagnosis of LCD display malfunction	All LCDs lit		

• Table 1: Input signal assignments

No.	Details	Application
0	Unused	Assignment inhibited
1	Pulse input signal (high speed)	Used in the division/multiplication mode.
2	Stop input	When stop input is input, pump operation stops and the LCD display blinks. The START key cannot be used while pump operation is stopped.
3	Start input	Used in the counter mode.
4	Start reset	Resets the current value to the setting value.
5	Alarm reset	Resets the alarm flag.
7	Level input	Displays and outputs an alarm when the level is input.
10	MAX operation	Operates the pump at 300 spm in all modes when this input is input.

\* For details on signal specifications, see "I/O Signal Specifications" (page 37).

• Table 2: Output signal assignments

No.	Details	Application
0	Unused	Assignment inhibited
1	All alarms	This is output when any alarm is output.
2	Operation sync pulse	This pulse signal is synchronized with solenoid drive.
3	Operation signal	This is output during operation. (including standby in progress)*1
4	Run signal	This is output during pump operation. (excluding standby in progress)*1
5	End signal	This is output when the preset count is reached in the count mode.
7	Level	Select this to individually output alarm outputs.
8	Pulse overflow	
9	Analog error	

\*1 Standby in progress: This is a state where the pump waits for pulses in the division/multiplication mode. During 4 mA input in the analog input mode Pump waiting for the start signal in the count/batch mode

# Troubleshooting



## WARNING

- Do not operate this pump with wet hands. Doing so might result in electric shock.
- Make sure to turn OFF the power before disassembling the liquid end and check that the power is not applied to the pump. Do not start the disassembly only by stopping the pump with a key. Attach a "Work In Progress" label to the power switch so that the power cannot be turned ON during repair works.
- When handling liquid-end sections, be sure to wear protective coverings (rubber gloves, mask, protective goggles, chemical-resistant overalls, etc.) appropriate for the chemicals being used.
- Before maintaining or repairing the pump, be sure to release the discharge-side pressure, drain the chemicals from liquid-end sections, and wash the pump.

## IMPORTANT

- We recommend using the flow indicator as a means of detecting defective discharge.

### During Operation

Description of trouble 1	Description of trouble 2	Cause	Remedial action
The pump does not turn on. (The display does not light.)		<ul style="list-style-type: none"><li>(1) Power supply or voltage trouble.</li><li>(2) Problem in the wiring connections to the pump.</li><li>(3) Broken power cable.</li><li>(4) Main power supply disconnection.</li><li>(5) The breaker has tripped.</li><li>(6) Circuit malfunction.</li></ul>	<ul style="list-style-type: none"><li>(1) Check the power supply and the voltage, and then connect the pump to the correct power supply.</li><li>(2) Inspect the wiring connections, and connect the wires properly.</li><li>(3) Check the power cable.</li><li>(4) Position the switch on the correct side.</li><li>(5) Investigate why the breaker has tripped, and then reset it.</li><li>(6) Replace the circuit.</li></ul>
The power turns on, but the pump does not operate.		<ul style="list-style-type: none"><li>(1) The STOP lamp lights.</li><li>(2) The displayed value blinks.</li></ul>	<ul style="list-style-type: none"><li>(1) Press the [STOP/START] key.</li><li>(2) Remove the stop input signal.</li></ul>
The pump operates. No chemical liquid is discharged. (The chemical liquid is not pumped up.)		<ul style="list-style-type: none"><li>(1) The chemical liquid is too viscous.</li><li>(2) The hose or valve is clogged.</li><li>(3) The hose aperture is too small or the pipe is too long.</li><li>(4) The stroke length is too short.</li><li>(5) The valve seats are clogged with dirt or deformed.</li><li>(6) The amount of chemical liquid remaining in the tank is low.</li><li>(7) The foot valve or the strainer is clogged.</li><li>(8) The pump is gas locked.</li><li>(9) The valve seat area has been assembled in the wrong direction.</li></ul>	<ul style="list-style-type: none"><li>(1) Lower the viscosity of the chemical liquid.</li><li>(2) Clean the hose and valve.</li><li>(3) Make the hose aperture larger or the pipe shorter.</li><li>(4) Increase the stroke length.</li><li>(5) Clean the valve seats or replace them. If the valve seats become deformed in a short period of time, use valve seats of a different material.</li><li>(6) Replenish the chemical liquid.</li><li>(7) Clean the foot valve, strainer, and tank.</li><li>(8) Release the air.</li><li>(9) Disassemble the valve seat area, and then re-assemble it correctly.</li></ul>
		<ul style="list-style-type: none"><li>(1) Gas is generated due to the properties of the chemical liquid.</li><li>(2) There is a leak in the joints, seal areas, or other parts.</li><li>(3) The chemical liquid tank is empty.</li></ul>	<ul style="list-style-type: none"><li>(1) Dilute the chemical liquid.</li><li>(2) Tighten the joints, seal areas, or other parts that are leaking.</li><li>(3) Replenish the chemical liquid, and then release the air.</li></ul>

# Troubleshooting

Description of trouble 1	Description of trouble 2	Cause	Remedial action
The pump does not operate at the maximum discharge pressure. (The drive sound registers weakly.)		(1) The power supply is not appropriate or the supply voltage is too low. (2) A thermal relay has been used as a protection device.	(1) Connect the pump to the correct power supply. (2) Change the thermal relay to a circuit protector.
Chemical liquid is leaking.	Chemical liquid is leaking from the joints.	(1) The hose and nuts are not tight enough. (2) The discharge-side pipe is clogged with dirt or other foreign material, which has caused the pressure to increase. (3) The hose connections have deteriorated.	(1) Tighten the hose and nuts. (2) Clean inside the pipe. (3) Replace the hose.
	Chemical liquid is leaking from the pump head.	(1) The head bolts are not tight enough. (2) The discharge-side pipe is clogged with dirt or other foreign material, which has caused the pressure to increase. (3) The diaphragm has suffered damage due to fatigue.	(1) Tighten the head bolts. (2) Clean inside the pipe. (3) Replace the diaphragm.
The discharge capacity is too small.		(1) Air has entered into the pump head. (2) The diaphragm has deteriorated or has been damaged. (3) The valve seat area has deteriorated or is clogged. (4) The pipe is clogged. (5) The suction height is outside of the specified range. (6) The chemical liquid is too viscous. (7) The discharge pressure is too high. (8) The stroke length is too short. (9) The suction-side hose or valve is clogged. (10) The foot valve or the strainer is clogged.	(1) Release the air. (2) Replace the diaphragm. (3) Clean the valve seats or replace them. (4) Clean inside the pipe. (5) Set the suction height to a value within the specified range. (6) Reduce the viscosity of the chemical liquid or change the joints to high-viscosity type joints. (7) Check the pressure and the specifications. (8) Increase the stroke length. (9) Clean the suction-side hose and valve or replace them. (10) Clean the foot valve, strainer, and chemical liquid tank.
The discharge capacity is too large.		(1) An overfeed has occurred. (2) A negative pressure has occurred on the discharge side. (3) The push pressure is too high.	(1, 2) If the pump is equipped with an anti-siphonal check valve, clean it. If the pump is not equipped with an anti-siphonal check valve, attach one to the pump. (3) Set the discharge-side pressure to a value that is higher than the push pressure.
The keys cannot be operated.		(1) The keys have been locked.	(1) Release the key lock.
The actual discharge capacity differs significantly from the value that was set in manual mode (discharge capacity setting mode).		(1) The wrong maximum discharge capacity has been set. (2) The stroke length is different from the one when the maximum value was set.	(1) Perform calibration, and then set the maximum value correctly. (2) Set the stroke length to the necessary value, and then set the maximum value correctly.
Pulse input cannot be received.		(1) Signal cable disconnection. (2) The signal input specifications are different.	(1) Check the signal cable. (2) Check the specifications.

# Troubleshooting

## Troubles in the Signal Input Mode

Details of Trouble	Cause	Remedy
Signals are not input according to preset division or multiplication ratio. (during pulse signal input)	(1) Noise on signal line	(1) Move the signal line away from the power line. Or, use shielded cable for the signal line.
Signal does not reach 20 mA. (during analog signal input)	(2) Insufficient signal drive	(2) Check the maximum drive resistance of the signal source.
Keys other than START/STOP key do not function.	(3) The key lock is active.	(3) Cancel the key lock. To cancel the key lock, stop pump operation, and hold down the SET key for at least two seconds with the FUNC key held down.
E-00 is displayed.	See Alarm Codes.	See Alarm Codes.

## Alarm Codes

The following codes appear on the display when an alarm occurs.

Alarm Code No.	Type	Cause of Alarm	Remarks
<b>E-01</b>	ROM write error	Pump error	Pump operation is stopped.
<b>E-02</b>	Abnormal level alarm	Level input" is set to the input port, and that port turned ON (short-circuited).	Select processing method in parameter P-32.
<b>E-03</b> *	Input pulse buffer overflow	The number of input pulses momentarily increased in the division/multiplication mode, and exceeded the preset buffer size.	Select processing method in parameter P-33.
<b>E-04</b> *	Abnormal analog input alarm (min to max)	The input signal went out of the specified value range during operation in the analog input mode.	Select processing method in parameter P-34.

\* When the trouble is solved, the alarm is automatically canceled, and the display returns to the regular display.

### • Mode in which alarms occur (only during pump operation)

Alarm Code No.	MAN	ANG	DIV · MUL	CNT · INT
E-01	●	●	●	●
E-02	●	●	●	●
E-03	—	—	●	—
E-04	—	●	—	—

● : Alarm occurs.

### • How to cancel alarms

<E-01>

- Try turning the power OFF then back ON again. If this does not solve the problem, a probable cause is a circuit error.

<E-02 to 04>

- Press the RESET key.
- Input an alarm reset from the external device.
- Press the STOP key to stop pump operation.

## ■Model Codes

**PZiG - 1300 - V T C E - 12x18PVC - W - S - JPL - X**

(1)

(2)

(3)

(4)

(5)

(6)

(7)

(8)

(9)

(10)

(11)

### (1) Series name

PZiG Series

### (2) Pump model

Type	Discharge Volume
300	340mL/min
500	530mL/min
700	760mL/min
1000	1000mL/min
1300	1300mL/min

### (3) Pump head materials

Type	Material
V	PVC
F	PVDF
X	Special

### (4) Diaphragm materials

Type	Material
T	PTFE

### (5) Check ball

Type	Material
C	Ceramic
X	Special

### (6) O-ring

Type	Material
E	EPDM
F	Fluoro-rubber
T	PTFE
X	Special

### (7) Connection

Type	
12 x 18 PVC	PVC braided hose 12 x 18mm dia.
12 x 15 PTFE	PTFE tube 12 x 15mm dia.
FNPT1/2	FNPT1/2"
FNPT3/4	FNPT3/4"
MNPT3/4	MNPT3/4"
VP20	VP20

### (8) Joint Specification

Type	Specification
W	Standard joint
V	High-viscosity joint

### (9) Applicable standard

Type	
S	Standard
CE	CE marking compatible

### (10) Power plug

Type	
EUP	Euro plug* <sup>1</sup>
ULP	UL plug
AUP	Australia plug
UKP	U.K. plug* <sup>1</sup>
JPL	Japanese lead wire

\*<sup>1</sup> CE mark certified

### (11) General specifications

Type	Specification
None	Standard
X	Special

## ■Performance Specifications

Specifications	Model	300	500	700	1000	1300
Max. discharge volume	mL/min	340	530	760	1000	1300
	L/h	20.4	31.8	45.6	60	78
	US G/h	5.38	8.39	12.03	15.84	20.59
Discharge volume per stroke (mL/stroke)		1.1	1.8	2.5	3.3	4.3
Max. discharge pressure	MPa	1.0 *1	0.7 *1	0.4	0.3	0.2
	bar	10	7	4	3	2
	psi	145	101	58	43.5	29
Max. number of strokes (spm)				300		
Stroke length (mm)				1.5		
Stroke length adjustment range (%)				20 to 100% adjustable		
Connection	For less than 50mPa·s (VTCE/VTCF)			PVC braided hose 12 x 18 mm dia. / FNPT 1/2		
	For less than 50mPa·s (FTCT)			PTFE tube 12 x 15 mm dia. / FNPT 1/2		
	For high-viscosity (VTCF)			FNPT3/4 / MNPT3/4 / VP20 union joint		
Operating temperature range	Ambient temperature			0 to 40°C		
	Transferrable temperature			0 to 40°C		
Transferrable viscosity (mPa·s)				50 or less (high viscosity: 3000 or less)*2		
Self-priming height (m)				-1.5		
Pump color	Pump case (front)			Munsell (approximately)10YR 7.5/14		
	Pump case (rear)			Munsell (approximately)5PB 6/2.5		
Weight (kg)				Approx. 11		

\*1 In the case of the FTCT using PTFE tube, this becomes 0.5 (MPa).

\*2 When transferring high-viscosity liquids, the discharge volume may fall below the specified maximum discharge volume depending on the characteristics of the liquid, transfer conditions and other factors.  
Consult us separately when transferring high-viscosity fluids.

## ■Power Supply Specifications

Specifications	Model	All models
Power supply voltage (Vac)	Rating	100 ~ 240
	Operating range	90 ~ 264
Frequency (Hz)		50/60
Number of phases (f)		1
Max. current (A)		4
Max. current consumption (VA)		750
Average current consumption (W)		100

- Use the maximum current when calculating the required power supply capacity.
- Be sure to use a commercial power supply (power supplied from an electric power company) as the power supply.
- Power supplies that cannot be used:
  1. Power supply equipped with an AC power regulator
  2. Power supply on the output side of the inverter
- When receiving power via a transformer, be sure to use a transformer with a capacity of at least three times the maximum power consumption.

## ■I/O Signal Specifications

Digital signals use sync logic (NPN). Please use a converter when connecting to a source logic (PNP) device.  
(Example of recommended equipment: DEK-TR/INV-2964319 manufactured by Phoenix Contact GmbH & Co. KG)

### • 4-pin connector

Category	Name	Type	Connection Pin No.	Standard
Input	Digital signal input [pulse signal input]	No-voltage contact O.C	1-4 (IN1, high speed)	Max. response speed 125 Hz (duty 50%) Input resistance: approx. 2 kΩ
	Analog signal	DC 4 ~ 20mA	2-4	Damping 1 sec or less Input resistance: approx. 110 Ω
	Digital signal input 2 [stop signal input]	No-voltage contact O.C	3-4 (IN2, low speed)	Max. response speed 10 Hz (duty 50%) Input resistance: approx. 2 kΩ non-lock operation

\*1 The input control function can be changed in the program. The function between [] is initial at the factory shipment.

\*2 Pin No.4 is common (- side).

### • 8-pin connector

Category	Name	Type	Connection	Standard
Input	Digital signal input [pulse signal input]	No-voltage contact O.C	1-3 (IN3, high speed)	Max. response speed 125 Hz (duty 50%) Input resistance: approx. 2 kΩ
	Digital signal [start reset]	No-voltage contact O.C	7-3 (IN4, low speed)	Max. response speed 10 Hz (duty 50%) Input resistance: approx. 2 kΩ
Output	Digital signal [all alarms]	O.C	4-6 (OUT1)	25 VDC/10 mA or less
	Digital signal [operation pulse]	O.C	5-6 (OUT2)	25 VDC/10 mA or less
Power supply	Sensor power supply	Stabilized power supply	2-3	+5 V/10 mA or less

\*1 The input control function can be changed in the program. The function between [] is initial at the factory shipment.

\*2 Connect pin No.3 to the input side and power supply common (- side), and to pin No.4 on the 4-pin side.

\*3 Pin No.6 is the output-side common (emitter side).

## ■Other Specifications


Specification	Data
Noise (dBA)	83 or less

## ■Performance Curves

The following performance curves are measurement examples obtained by measuring on test equipment at TACMINA. These performance curves may differ slightly depending on various on-site conditions and product differences. Measure the discharge volume under actual operating conditions, and set the strokes according to the performance curve that is obtained.

### • Basic specifications

Conditions: clean water, room temperature




## ■ Discharge Performance of High-viscosity Liquids

When a fast stroke speed is set for transferring high-viscosity liquids, piping resistance on the suction side may cause the amount of sucked in liquid to be reduced.

### PZiG-1300-VTCF-VP20-V-S

Conditions: Room temperature




## ■ Length of Discharge-side Piping and Discharge Volume

The graph below shows the relationship between piping length and discharge volume. Installing a damper lessens piping resistance and allows the length of the piping to be extended.

### PZiG-1300-VTCE-12x18-W-S


Conditions: Room temperature, clean water



## ■External Dimensions (mm)


PZiG-300/500/700/1000/1300-VTCE/VTCF-12 x 18PVC-W-

	A	B	C	D	E
PZiG-300/500-VTCE/VTCF-12 x 18PVC-W-	112	224	282	49.5	246
PZiG-700-VTCE/VTCF-12 x 18PVC-W-	103	206	273	53.5	253
PZiG-1000/1300-VTCE/VTCF-12 x 18PVC-W-	105	210	275	53.5	253




PZiG-300/500/700/1000/1300-VTCE/VTCF-FNPT1/2-W-

	A	B	C	D	E
PZiG-300/500-VTCE/VTCF-FNPT1/2-W-	100	200	270	49.5	246
PZiG-700-VTCE/VTCF-FNPT1/2-W-	90	180	260	49.5	246
PZiG-1000/1300-VTCE/VTCF-FNPT1/2-W-	95	190	265	53.5	253




## ■External Dimensions (mm)



PZiG-300/500/700/1000/1300-VTCF-VP20-V-



PZiG-300/500/700/1000/1300-VTCF-FNPT3/4-V-




## ■External Dimensions (mm)

PZiG-300/500/700/1000/1300-VTCF-MNPT3/4-V-																							
PZiG-300/500/700-VTCF-MNPT3/4-V-	A	B																					
PZiG-1000/1300-VTCF-MNPT3/4-V-	246	49.5																					
PZiG-300/500/700/1000/1300-FTCT-12 x 15PTFE-W-	A	B																					
PZiG-300/500/700-FTCT-12 x 15PTFE-W-	115	97	212	285	49.5	246																	
PZiG-1000/1300-FTCT-12 x 15PTFE-W-	128	128	256	298	53.5	253																	
																							
<table border="1"> <tr> <td>PZiG-300/500/700-VTCF-MNPT3/4-V-</td><td>A</td><td>B</td></tr> <tr> <td>PZiG-1000/1300-VTCF-MNPT3/4-V-</td><td>246</td><td>49.5</td></tr> </table>			PZiG-300/500/700-VTCF-MNPT3/4-V-	A	B	PZiG-1000/1300-VTCF-MNPT3/4-V-	246	49.5															
PZiG-300/500/700-VTCF-MNPT3/4-V-	A	B																					
PZiG-1000/1300-VTCF-MNPT3/4-V-	246	49.5																					
<table border="1"> <tr> <td>PZiG-300/500/700-FTCT-12 x 15PTFE-W-</td><td>A</td><td>B</td><td>C</td><td>D</td><td>E</td><td>F</td></tr> <tr> <td>PZiG-300/500/700-FTCT-12 x 15PTFE-W-</td><td>115</td><td>97</td><td>212</td><td>285</td><td>49.5</td><td>246</td></tr> <tr> <td>PZiG-1000/1300-FTCT-12 x 15PTFE-W-</td><td>128</td><td>128</td><td>256</td><td>298</td><td>53.5</td><td>253</td></tr> </table>			PZiG-300/500/700-FTCT-12 x 15PTFE-W-	A	B	C	D	E	F	PZiG-300/500/700-FTCT-12 x 15PTFE-W-	115	97	212	285	49.5	246	PZiG-1000/1300-FTCT-12 x 15PTFE-W-	128	128	256	298	53.5	253
PZiG-300/500/700-FTCT-12 x 15PTFE-W-	A	B	C	D	E	F																	
PZiG-300/500/700-FTCT-12 x 15PTFE-W-	115	97	212	285	49.5	246																	
PZiG-1000/1300-FTCT-12 x 15PTFE-W-	128	128	256	298	53.5	253																	
																							
<table border="1"> <tr> <td>PZiG-300/500/700-VTCF-MNPT3/4-V-</td><td>A</td><td>B</td></tr> <tr> <td>PZiG-1000/1300-VTCF-MNPT3/4-V-</td><td>246</td><td>49.5</td></tr> </table>			PZiG-300/500/700-VTCF-MNPT3/4-V-	A	B	PZiG-1000/1300-VTCF-MNPT3/4-V-	246	49.5															
PZiG-300/500/700-VTCF-MNPT3/4-V-	A	B																					
PZiG-1000/1300-VTCF-MNPT3/4-V-	246	49.5																					

## ■External Dimensions (mm)

PZiG-300/500/700/1000/1300-FTCT-FNPT-1/2-W-						
	A	B	C	D	E	F
PZiG-300/500/700-FTCT-FNPT-1/2-W-	115	97	212	285	49.5	246
PZiG-1000/1300-FTCT-FNPT-1/2-W-	128	128	256	298	53.5	253



The technical drawing illustrates the external dimensions of the PZiG-300/500/700/1000/1300-FTCT-FNPT-1/2-W- series motor. The front view on the left shows a circular base with a diameter of 150 mm and a height of 165 mm. The side view on the right shows the motor's height (A), width (B), and depth (C). The side view also includes a top-down view of the base showing a central hole with a diameter of 14 mm. Dimension D is the total height of the motor, which is 170 mm. Dimension E is the width of the base, which is 38 mm. Dimension F is the total width of the motor, which is 170 mm. A small 'TACMERA' logo is visible on the base.

# Consumables and Spare Parts

## ■ Consumables

The recommended replacement cycles are for cases where the pump is operated under constant conditions (room temperature and clean water). These cycles change according to individual site conditions. Use these cycles as rough guidelines for replacing consumables. Neglecting to replace consumables may cause defective discharge (injection) or malfunction.



### CAUTION

- The durability of hoses, tubes, relief/air release hoses, anti siphonal check valves, and foot valves varies considerably depending on the chemical used, temperature, pressure, and UV rays. Inspect these and replace them when they have deteriorated.

Part Name	Q'ty Per Unit	Recommended Replacement Cycle
Joints	Valve seat	See "Replacing the Valve Seat and Check Ball" on page 28. 4,000 hours after start of operation or 1 year
	Check ball	
	O-ring	
	Spring (high-viscosity specification only)	
Diaphragm	1	
Protective diaphragm	1	

\* Use whichever arrives first, 4,000 hours after start of operation, or 1 year.

## ■ Spare Parts

- Hose nut
- Retaining ring
- Hose joint

## ■ Options

### ● Damper

This option reduces pulsation on the discharge-side piping, and lessens piping resistance, allowing the length of the piping to be extended.

### ● Signal cable

For 4-pin: 2 m, 5 m      For 8-pin: 2 m, 5 m

### ● Relief valve

The valve automatically releases pressure when excessive pressure occurs in the pump's discharge-side piping due to clogging by foreign objects or a closed valve.

### ● Back pressure valve

This valve is used to prevent the "overfeeding"; the phenomenon that causes the flow of liquids at an excessive discharge volume depending on the piping condition.

# After-sales Services

If any aspects of the terms and conditions of the after-sales service applying to the repairs to be provided during the warranty period and other such matters are not clear, consult your vendor or a TACMINA representative.

## Warranty

- (1) The warranty period shall be one year from the date of dispatch from TACMINA's factory.
- (2) If, during the warranty period, the product sustains malfunctions or damages as a result of design, manufacturing, or material defect, or if the product does not meet its specifications, TACMINA will arrange for repairs, provide replacement components, or replace the product, at TACMINA's discretion, at no charge to the customer. However, this warranty only covers direct damage to the product. Any consequential losses or damages, including, but not limited to, profit losses and any secondary damages, caused by malfunctions, breakage, or impaired performance of this product shall not be covered by this warranty. The limitation of TACMINA's liability shall not exceed the sales value of the defective product.
- (3) If a malfunction or damage is found, notice shall be given to distributor or TACMINA with documents that prove the malfunction or damage is caused by improper design, manufacturing failure or material defect within 14 days after awareness of such malfunction or damage. If the distributor or TACMINA does not receive such notice within aforementioned period, even though the warranty period is still in effect, TACMINA shall not be liable for any malfunction and damage.  
Please note that TACMINA may request to give further information or to return the product for investigation. If the cause is attributable to TACMINA's action, the shipping fees, cost of investigation and checks performed by TACMINA shall be borne by TACMINA.
- (4) Even in the warranty period, the cost of repairs in the following conditions shall be paid to the distributor or TACMINA.
  - 1) Damages and deterioration of consumables.
  - 2) Damages or malfunctions of the warranted product caused by carelessness in handling or incorrect use.
  - 3) Damages or malfunctions of the warranted product caused by the failure to perform maintenance such as periodic inspections and repairs and replacements of consumables.
  - 4) Damages or malfunctions of the warranted product caused by falls or impacts.
  - 5) Damages or malfunctions of the warranted product resulting from the use of parts other than the ones supplied by TACMINA.
  - 6) Damages or malfunctions of the warranted product resulting from product repairs or remodeling undertaken by individuals other than TACMINA employees or personnel of businesses authorized by TACMINA.

### ■Minimum retention period for consumables

TACMINA will continue to supply consumables for its pumps for a period of eight (8) years after the manufacture of the pumps has been discontinued.

- 7) Damages or malfunctions of the warranted product resulting from fires, natural disasters, geological calamities, and force majeures.
- 8) Damages or malfunctions of the warranted product resulting from loose bolts or nuts or from defective hose connections.
- 9) Discoloration, deterioration, damages, or malfunctions of the warranted product resulting from ultraviolet rays, corrosive gases, or flooding.
- 10) Damages or malfunctions of the warranted product resulting from corrosion, swelling, or melting caused by the adhesion or chemical effect of the used liquid.
- 11) Damages or malfunctions of the warranted product resulting from damages to products other than those made by TACMINA.
- 12) Damages or malfunctions of the warranted product resulting from usage outside of the range of the usage conditions listed in the operation manual.
- (5) The judgment of damages, malfunctions, and impaired performance as well as the judgment of whether the cause is the design of the product and product defects shall be performed by TACMINA's technical department.

## Repairs

### ■Before requesting repairs

Please read this operation manual carefully and inspect the product again.

### ■Who to request repairs from

Ask your vendor to take care of the repairs. If you are not sure of who your vendor is, contact TACMINA.

### ■Precautions when sending the product for repairs

Be sure to observe the following items to protect worker safety and to protect the environment:

- If any chemicals have affixed to the product, wash it clean.
- Attach the safety data sheet (SDS) to the product.
- If a "maintenance data" page is present at the end of the operation manual, fill in this page and attach it to the product.
- \* The product may not be repaired if the necessary materials are not attached.
- \* Even when the necessary materials are attached, TACMINA may send the product back if it is determined that repairing the product will constitute risks or dangers.

Product designs and specifications are subject to change without notice for product improvement.

## TACMINA CORPORATION

**Head Office:**  
2-2-14 Awajimachi, Chuo-ku, Osaka 541-0047 Japan  
Tel.+81(0)6-6208-3974 Fax.+81(0)6-6208-3978  
URL [www.tacmina.com](http://www.tacmina.com)  
E-mail [trade@tacmina.com](mailto:trade@tacmina.com)

EM-110(16)-
2025/4/l--

Z1165

